

Z AXIS TORRINGTON BEARING UPGRADE

For use on CNC drives without ball screw assembly.

You will need 1 each-

12 MM Torrington bearing

15 MM “ “

Install the Torrington bearings on either side of the steel mounting plate and set the dial and cnc drive pulley tight against them as shown in the illustration. This will reduce the drive friction on the cnc system and prevent lateral motion of the worm shaft which can cause backlash.

